
3-862-343-03(1) SONY

マイクロカセット™コーダー

取扱説明書 Operating Instructions

お買い上げいただきありがとうございます。



や人身事故になることがあります。


この取扱説明書には、事故を防ぐための重要な注意事項と製品の取 り扱いかたを示しています。この取扱説明書と別冊の「安全のため に」をよくお読みのうえ、製品を安全にお使いください。 お読みになったあとは、いつでも見られるところに必ず保管してく ださい。

M-100MC

Sony Corporation © 1998 Printed in China

ご注意

- 録り直しのきかない録音の場合は、必ず事前にためし録りをしてくだ
- ・マイクロカセットコーダーの不具合により録音されなかった場合の録 音内容の補償については、ご容赦ください。
- ・カセットテープは(MICROCASSETTE)™の表示があるものをご使用くださ い。この表示のないテープは、このマイクロカセットコーダーでは使 用できない場合があります。(<mark>A</mark>)
 - テープA面には小さなくぼみが あり、暗いところでもA面B面の 区別ができます。





MICROCASSETTE
™以外のテープ

・ あなたが録音したものは、個人として楽しむなどのほかは、著作権法 上、権利者に無断では使用できません。


ソニー株式会社 〒141-0001 東京都品川区北品川6-7-35

東京(03)5448-3311 名古屋(052)232-2611 大阪(06)539-5111

お問い合わせはお客様ご相談センターへ

- 録音状況に応じてマイクの感度、および指向性を3段階(講義、会議、 口述)に切り換えることができる録音モード切り換えスイッチ。
- 電池の消耗を2段階で知らせる電池(残量)ランプと電池の交換時期を知 らせる⇔(電池交換)ランプ。
- 録音内容ごとに信号音を入れておくことにより、キュー/レビュー時に 頭出しができる、キューマーカー機能。 • 再生の速度を普通の速度より速め、効率良く聞き返すのに便利なファー
- ストプレイバック(速聞き再生)機能。
- 一定の強さ以上の音声を検知して自動的に録音が始まり、それ以下の音 声になるとテープが止まるVOR(自動音声録音スタート)機能。
- 再生モードから直接録音モードにできる後追い録音機能。
- テープカウンター
- 再生・録音時にテープの終わりで自動的に動作が止まる、オートシャッ トオフ機能。
- 停止ボタンを押すと一時停止も解除される、ストップポーズリリース機 能。解除を忘れて録音チャンスを逃してしまう失敗を減らします。

各部のなまえB



- 1 ■■一時停止スイッチ
- 2 キューマーカーボタン
- 3 音量つまみ 4 録音ランプ
- 5 マイク
- 6 スピーカー
- 7 録音モード切り換えス イッチ
- 8 電池(残量)ランプと□ (電池交換)ランプ
- 9 ●(録音)ボタン
- 10 ►(再生)ボタン

- ▶▶(早送り)/キュー
- •◀◀(巻き戻し)/レビ ューつまみ
- - 12 VORスイッチ 13 ファーストプレイバッ クスイッチ
 - 14 ハンドストラップ
- 15 テープスピード 切り換 えスイッチ
- 16 イヤホンジャック 17 DC IN 3Vジャック
- 18 (停止/取り出し)ボ タン
- 19 テープカウンター

乾電池を入れる


ここでは乾電池での使いかたを説明します。コンセントでの使いかたは、 「電源について」をご覧ください。

付属の乾電池を入れる 〇-②

①押しながら矢印の方向へずらす




②単3形乾電池2本を入れる




新しい乾電池と使用した乾電池、または種類の違う乾電池を混ぜて使用しないでく

乾電池を取り出すときは 🖸 - 6



電池入れのふたがはずれたときは 〇一〇

電池入れのふたは、開けるときに過大な力を加えると、はずれるようにな っています。はずれた場合は図のようにふたを溝に通して取り付けてくだ さい。



録音する

内蔵マイクですぐに録音できます。

1 カセットを入れる ①-@

押してふたを開ける

①■ 4 (停止 / 取り出し)を ②録音を始める面をふた側 にしてカセットを入れる



2 テープスピードを選ぶ D-b




3 録音モードを合わせるD-©




4 VORスイッチを「切」にする **D**-(d)

ここでは通常の録音のしか たを説明します。VOR機能 を使った録音については 「録音の便利な機能を使う」 をご覧ください。



5 録音する D-@




	押すボタン、ずらすつまみ
録音を止める	■ • (停止/取り出し)
一時停止する	■■一時停止スイッチを矢印の方向にずらす。録
	音ランプと電池(残量)ランプが消灯する。
	一時停止を解除するには、Ⅲ一時停止スイッチ
	を元に戻す。
カセットを取り出す	■ ◀ (停止 / 取り出し)

テープを聞く

内蔵スピーカーから音が聞こえます。

1 カセットを入れる 匡-@

①■ (停止/取り出し)を ②再生を始める面をふた側 押してふたを開ける にしてカセットを入れる



2 テープスピードを選ぶ E-b



3 再生する E-©



テープを止める	■ ┫ (停止 / 取り出し)
一時停止する	■■一時停止スイッチを矢印の方向にずらす。電池(残
	量)ランプが消灯する。
	一時停止を解除するには、■■一時停止スイッチを元
	に戻す。
	停止中に▶▶(早送り)/キュー•◀(巻き戻し)/レビュー
	つまみを▶▶(早送り)/キューの方向にずらす。**
巻き戻す*	停止中に▶▶(早送り)/キュー•◀◀(巻き戻し)/レビュー
	つまみを◀◀(巻き戻し)/レビューの方向にずらす。**
音を聞きながら	再生中に▶▶(早送り)/キュー•◀◀(巻き戻し)/レビュー
早送りする	つまみを▶▶(早送り)/キューの方向にずらす(指を離
(キュー)	すとそこから再生する)。**
音を聞きながら	再生中に▶▶(早送り)/キュー•◀(巻き戻し)/レビュー
巻き戻す	つまみを◀◀(巻き戻し)/レビューの方向にずらす(指
(レビュー)	を離すとそこから再生する)。**


- 早送り、巻き戻しをしてテープが巻き取られたあと、そのままにしておっ と電池が急激に消耗するので必ず■ 4 (停止/取り出し)ボタンを押してく
- ** テープは巻き戻し/レビュー時のほうが早送り/キュー時よりも速く巻き取 られます。

-----再生中に巻き戻し(レビュー)をしてテープの始めまで巻き取られた時、指 を離しても▶▶(早送り)/キュー•◀◀(巻き戻し)/レビューつまみが中央に戻ら ないことがあります。このような場合は、つまみを中央に戻すと再生が始ま

テープを速聞きするには(ファーストプレイバック) ファーストプレイバックスイッチを矢印の方向にずらします。元の

速度に戻すには矢印の反対方向にずらします。効率良く聞き返した いときに便利です。

録音の便利な機能を使う「F



テープカウンターを使う

録音を始める前に、テープカウンターのリセットボタンを押して「000」に します。録音の頭を探すのに便利です。

テープ速度

テープスピード切り換えスイッチでテープ速度を選びます。 2.4cm: 通常の録音をするとき

「1.2 cm」のときより良い音で録音できます。 1.2cm: テープを2倍の長さに使って録音するとき (MC-60を使うと往復120分の録音ができます。)

• 再生は録音と同じテープスピードで行ってください。他のマイクロカセットレコー ダーで再生する可能性のある場合は、なるべく2.4cm/sの速さで録音してくださ い。1.2cm/sの速さで録音したテープを、他のマイクロカセットレコーダーで再生 すると、再生音が異なる場合があります。

音がしたとき自動的に録音を始める(VOR機能)

VORスイッチを「入」に切り換えておきます。

●(録音)ボタンを押すと、ある大きさ以上の音をマイクが拾うと自動的に 録音が始まり、音が小さくなると止まります。録音の途中でテープを止め る手間がはぶけるので口述録音するときに便利です。また、空録音の部分 がなくなり、テープが有効に使えます。

- ▼VOR機能は周囲の環境に左右されます。VORスイッチを操作しても思い通りに録 音できないときは、VORスイッチを「切」にしてください。
- 音を感じてから録音が始まるので、言葉の初めの部分は録音されないことがありま す。大切な録音のときは、VORスイッチを「切」にしてください。

録音モードを変えて録音するには G

研修会などで、特定の人の声を集中的に録音したいとき、会議などの発言 を録音したいとき、または、口述録音したいときなど、それぞれに合った マイク感度と指向性に切り換えることができます。録音モード切り換えス イッチを「講義」、「会議」、「口述」のどれかに合わせます。



(マイク感度:高、

単一指向性)

(マイク感度

(マイク感度: 低、全指向性 1

録音中の音を聞くには

付属のイヤーレシーバーをイヤホンジャックにつなぎます。(奥までしっか りと差し込んでください。) 聞こえる音量は一定で音量つまみで調節することはできません。

後追い録音をする

再生中に●(録音)ボタンを押すと、そこから録音状態になります。録音した ものの一部分を修正したいときなどに便利です。

録音したものをすぐに聞く(ワンタッチレビュー)

録音中に▶▶(早送り)/キュー・◀◀(巻き戻し)/レビューつまみを◀◀(巻き戻 し)/レビューの方向にずらすとテープが巻き戻され、手を離すとそこから 再生が始まります。

キューマーカーを録音するには

録音中にキューマーカーボタンを押すことによって、目印としての信号を 録音することができます。

キューマーカーボタンを押すと、録音ランプが消灯して、信号がテープに 録音されます。さらに長い信号を録音したい場合は、ボタンを押し続けて ください。 再生状態で早送りをしたり(キュー) 巻き戻したり(レビュー)すると、

信号が録音されているところで音(ピー)がして知らせます。また、再生中 も低い音(ブー)が聞こえます。

キューマーカーは音声のとぎれたところでお使いください。

• キューマーカーの信号音はキュー時とレビュー時では音質が異なります。また、テ プの最初と最後では巻き取られる速度が異なるため、テープの箇所によっても音

質が変わります。 テープが終わりまでくると(オートシャットオフ機構)

録音または再生状態でテープが終わりまで巻き取られると、押し込まれて


いたボタンは自動的に元に戻ります。 早送り、巻き戻しをしたときは▶▶(早送り)/キュー・◀◀(巻き戻し)/レビュ

大切な録音を守るには H

- つまみを中央に戻してください。

カセットのツメを折ると録音状態にできなくなるので、録音した音声を誤 って消してしまうミスが防げます。ツメを折っても穴をふさぐと再び録音 できます。図に示された部分以外にはテープを貼らないでください。

ツメの折りかた



セロハンテープ

再び録音するには

本機を再生状態にして、接続したモノラルテープレコーダーを録音状態に


他のテープレコーダーへ録音する

- 接続コード類のプラグはしっかり差し込んでください。
- 上の例はソニー製品の場合です。他社製品との接続がうまくいかないと きは、その製品の説明書をご覧ください。

スタンドを使って J-@

スタンドを使ってマイクの向きを変えることによって、余分な音を拾わ ず、よりクリアな録音ができます。特に、録音モードが「講義」のときは、 スタンドを使うとマイクを音源の方向に向けて録音することができ、便利 です。スタンドの立てかたは次の2通りあります。録音状況の合った方をお 使いください。





口に差し込みます。

スタンドがはずれたときは**J**-b

スタンドは過大な力を加えると、はずれるようになっています。はずれた 場合には、図のようにして取り付けてください。



電源について

乾電池の持続時間

使用電池	録音時(EIAJ*)
ソニーアルカリ乾電池LR6(SG)使用時	約16時間
ソニー乾電池ニュースーパーR6P(SR)使用時	約5.5時間


「EIAJ(日本電子機械工業会)規格による測定値です(ソニーマイクロカセットテー

乾電池は持続時間の長いアルカリ乾電池をおすすめします。

------電池持続時間は使用条件によって、短くなる場合があります。


乾電池を交換する時期 K-@

電池が消耗すると、テープ走行が不安定になったり雑音が多くなったりし ます。再生/録音中に⇔(電池交換)ランプが点滅したら、乾電池を2本とも 新しいものと交換してください。



- ・△□(電池交換)ランプが点滅し始めても、しばらくはテープが動きますが、正常な音 で再生できなくなり、録音時には、雑音が録音されたり、録音される音が小さくな りますので、必ず乾電池を交換してください。 ・ ⇔(電池交換)ランプが点滅して、乾電池の交換時期を知らせるのは、再生 / 録音
- 時、および一時停止時(VOR使用時の一時停止も含む)です。
- 次のような場合には電池を交換する必要はありません。
- · 再生中に音量を上げたときなどに(電池交換)ランプが音に応じて一時的にちら ついた場合。
- · テープの動きはじめやテープの終わりで、⇔(電池交換)ランプが瞬間的に点灯し
- ・早送り(キュー)/巻き戻し(レビュー)中に⇔(電池交換)ランプが点滅した場
- ・別売りの充電式電池でお使いの場合、充電してあっても電池(残量)ランプが1つし か点灯しないことがあります。

コンセントにつないで使う K-b



1 別売りのACパワーアダプターAC-E30Mを本体のDC IN 3Vジャック につなぎます。

2 ACパワーアダプターをコンセントにつなぎます。

_____ この製品には、別売りのACパワーアダプターAC-F30M(極性統一形プラグ・FIAJ 規格)をご使用ください。上記以外のACパワーアダプターを使用すると、故障の原因 になることがあります。

極性統一形プラグ

使用上のご注意

録音について

- カセットテープは(MICROCASSETTE)™の表示があるものをご使用ください。
- •録音中、マイクを電灯線や蛍光灯に近づけすぎると、ノイズが入ることがありま

乾電池について

乾電池の使いかたを誤ると、液もれや破裂のおそれがあります。次のことは必ずお守 りください。

- ⊕と⊝の向きを正しく入れてください。
- ・乾電池は充電できません。
- 長い間使わないときは、取り出しておいてください。
- 液もれが起こったときは、液をよくふきとってから新しい乾電池を入れてくださ
- 持ち運ぶときはキーホルダーなどの金属類と一緒にポケットに入れないでくださ い。乾電池の⊕⊖が金属とつながるとショートし、発熱して危険です。
- ・別売りのACパワーアダプターやカーバッテリーコードをDC IN 3Vジャックにつな いでいると、乾電池ではお使いになれません。


環境汚染の軽減と経済性を考えて -

本機は、乾電池の他に

- 別売りの二カド充電式電池NC-AA-2B(別売りのバッテリーチャージャー BC-30K2にて充電可能)
- 別売りのAC パワーアダプターAC-E30M でもお使いになれます。
- 取り扱いについて

- ・落としたり、強いショックを与えたりしないでください。故障の原因になります。 次のような場所には置かないでください。
- -温度が非常に高いところ(60 以上)。
- 直射日光のあたる場所や暖房器具の近く。
- -窓を閉めきった自動車内(特に夏季)。
- -風呂場など湿気の多いところ。
- ー磁石、スピーカー、テレビなど磁気を帯びたものの近く。 ーほこりの多いところ。
- 長い間使わなかったときは、再びお使いになる前に、数分間再生状態にして空回し をしてください。良い状態でお使いいただけます。
- キャッシュカードや定期券など、磁気を利用したカード類をスピーカーに近づける と、マグネットの影響で磁気が変化してカードが使えなくなることがありますので、 ご注意ください。
- 万一故障した場合は、内部を開けずにお買い上げ店またはソニーサービス窓口にご相 談ください。

お手入れL



よい音でテープを聞くために

10時間程度使ったら、▶(再生)ボタンを押し込んだあとに、別売りのクリ ーニングキット(KK-41)でヘッド、キャプスタン、ピンチローラーをきれ いにしてください。

本体表面が汚れたときは

水気を含ませた柔らかい布で軽くふいたあと、からぶきします。シンナーや ベンジン、アルコール類は表面の仕上げを傷めますので使わないでくださ

故障かな?

終理に出す前にまる 1 度や調べてださい

修理に出す前にもう1度お調べください。		テープ	(MICROCASSETTE) [™] マイクロカセットテープ	
	原因/処置	トラック方式 スピーカー	マイクロカセットモノラル 直径28mm	
力セットが入らない。	カセットの向きが正しくない。	テープ速度 周波数範囲(EIAJ*)	2.4cm/s、1.2cm/s のスピード切り換え	
	►(再生)ボタンが押し込まれている。		「講義」: 400~3,000 Hz	
●(録音)ボタンが押し込めない。	カセットが入っていない。	出力端子 実用最大出力	「会議」、「口述」: 400~4,000 Hz イヤホン(ミニジャック)(1) 負荷インピーダンス 8~300 のイヤホン用 220 mW (EIAJ*) DC 3V、単3形乾電池2本使用 約126.0×68.0×40.8 mm (幅/高さ/奥行き)(EIAJ*) 最大突起部含む 本体約140g ご使用時 約180g(乾電池R6P(SR)2本、マイクロカセットテープMC-60含む) ソニー乾電池R6P(SR)(2) マイクロカセットテープMC-30(1) モノラルイヤーレシーバー(1) ウインドスクリーン(1) 取扱説明書(1) 保証書(1) ソニーご相談窓口のご案内(1) ACパワーアダプター AC-E30M(極性統一形プラグ・EIAJ*規格) カーパッテリーコード DCC-E230 接続コード RK-G64	
	カセットのツメが折れている。→録音内容を消してもよい場合は穴をふさぐ。			
●(録音)や►(再生)ボタンが 押し込めない。	テープが終わりまで巻き取られている。	電源最大外形寸法		
	オートシャットオフの後、■一時停止スイッチが矢 印の方向へずらされている。			
操作ボタンを押しても動作し	・乾電池の⊕と⊖の向きが正しくない。	質量		
ない。	・乾電池が消耗している。→2本とも同じ種類の新しいものと交換する。			
	■一時停止スイッチが矢印の方向へずらされている。			
	 ACパワーアダプターやカーバッテリーコードが本体に差したままになっている。 →ACパワーアダプターやカーバッテリーコードがジャックに差してあると、それが優先されるので、乾電池使用時には本体から抜いておく。 	別売りアクセサリー		
スピーカーから音が出ない。	イヤホンが差し込まれている。			
	• 音量が最小になっている。			
音が小さい。	• 音量が絞られている。		女成コード KK-G04 クリーニングキット KK-41	
音質がよくない。 雑音が入る。	・乾電池が消耗している。 →2本とも同じ種類の新しいものと交換する。	*EIAJ(日本電子機械工業会)規格による測定値です。		
• ヘッドが汚れている。		は、改良のため予告なく変更することがありますが、ご了承く		
キュー(早送り)/レビュー(巻き戻し)中、途中で止まる。または動かない。 早送りや巻き戻しができない。	・乾電池が消耗している。 →2本とも同じ種類の新しいものと交換する。	ださい。		
	テープスピード切り換えスイッチの位置が録音時と 違う位置にある。		フターサーピス	
再生速度が通常より速い。	ファーストプレイバックスイッチが矢印の方向へずらされている。	保証書 ・この製品には保証書が添付されていますので、お買い上げの際お買い上げ店でお受		
録音できない。	・乾電池が消耗している。 →2本とも同じ種類の新しいものと交換する。	け取りください。 ・所定事項の記入および記載内容をお確かめのうえ、大切に保存してください。 ・保証期間はお買い上げ日より1年間です。 アフターサービス		
	ヘッドが汚れている。→クリーニングする。			
	• VORが働いている。VORを使用しないときは、ス	調子が悪いときはま		

イッチを「切」にする。

イッチを「切」にする。

→クリーニングする

ていない。

前の音が完全には消えない。 ・ヘッドが汚れている。

録音モード切り換えスイッチがきちんと切り換わっ

• VORが働いている。VORを使用しないときは、ス

主な仕様

アフターサービス

調子が悪いときはまずチェックを

この説明書をもう一度ご覧になってお調べください。

それでも具合の悪いときはサービスへ

お買い上げ店または添付の「ソニーご相談窓口のご案内」にあるお近くのソ ニーサービス窓口にご相談ください。

保証期間中の修理は

保証書の記載内容に基づいて修理させていただきます。詳しくは保証書を ご覧ください。

保証期間経過後の修理は

修理によって機能が維持できる場合は、ご要望により有料修理させていた だきます。

部品の保有期間について

当社ではマイクロカセットコーダーの補修用性能部品(製品の機能を維持す るために必要な部品)を、製造打ち切り後最低6年間保有しています。この 部品保有期間を修理可能な期間とさせていただきます。保有期間が経過し た後も、故障箇所によっては修理可能の場合がありますので、お買い上げ 店またはサービス窓口にご相談ください。なお、補修用性能部品の保有期 間は通商産業省の指導にもよるものです。

As you read, refer to the illustrations in the Japanese corresponding text (labeled with A, B, etc.)

► Getting Started

Index to Parts and Controls B 1 ■ ■ 一時停止 (pause) switch キューマーカー (cue marker) button 音量 (volume) control 録音 (recording) indicator Microphone Speaker 録音モード (recording mode) selector 雷池 (battery) indicators and ⇔ indicator ご使用時 約180g(乾電池R6P(SR)2本、マイクロカセ • (recording) button (playback) button ▶▶ (fast-forward)/キュー(cue)・◀ (rewind)/レビュー(review)

switch VOR switch ファーストプレイバック (fast playback) switch

テープスピード (tape speed) switch イヤホン (earphone) jack DC IN 3V jack

ACパワーアダプター AC-E30M(極性統一形プラグ・ ■ **(**stop/eject) button 9 テープカウンター (tape counter)

Preparing Power Sources

Choose one of the following power sources.

Dry Batteries C-@

Make sure that nothing is connected to the DC IN 3V jack.

- 1 Open the battery compartment lid. Insert two R6 (size AA) batteries with correct polarity and close the lid

To take out the batteries C-b

To attach the battery compartment lid, if it is accidentally detached C-© Attach it as illustrated.

When to replace the batteries K-@

Replace the batteries with new ones when the 電池 (battery) indicators go off and the 🖾 indicator flashes. The battery indicators change as illustrated

- The unit will play back normally for a while, even after the △ indicator flashes. However, replace the batteries as soon as you can. If not, the playback cannot be made with normal sound, noise may be recorded and the recorded sound will not be
- loud enough • The 🖾 indicator flashes to indicate battery replacement during playback, recording
- and pause (during pause by VOR function also) In the following cases you do not need to replace the batteries:
- if the battery indicators flash with the playback sound when you turn up the - if the ♥ indicator lights momentarily when the tape starts running or at the end of
- if the ➡ indicator flashes during fast forward/cue or rewind/review

Battery life (Approx. hours) (EIAJ*)


Batteries	Recording
Sony alkaline LR6 (SG)	16.0
Sony R6P (SR)	5.5

Measured value by the standard of EIAJ (Electronic Industries Association of Japan) (Using a Sony Microcassette MC-60)

The battery life may shorten depending on the operation of the unit.

House current K-6

Connect the AC power adaptor to the DC IN 3V jack and to a wall outlet. Use the AC-E30M AC power adaptor (not supplied). Do not use any other AC power adaptor.



► Operating the Unit

Recording

- 1 Press **4** and insert a standard microcassette with the side to start recording facing the lid. D-@
- Select the desired tape speed. D-6
- 2.4cm for optimum sound (recommended for normal use): A 30-minute recording can be made using both sides of the MC-30 microcassette. **1.2cm** for longer recording time: A 60-minute recording can be made using both sides of the MC-30 microcassette. 3 Set 録音モード (recording mode) to select the sensitivity of the
- microphone (see "Using the recording mode selector"). D-© 4 Set VOR to 入 (on) or 切 (off). D-d
- If you set VOR to λ (on), the unit automatically starts recording the sound and pauses when there is no sound (you can save tapes and
- When the sound is not loud enough, set it to 切 (off), or the unit may not start recording
- 5 Press **●**. **D**-**e**

batteries).

Recording starts. While the tape runs, the 録音 (recording) indicator lights and flashes depending on the strength of the sound.

То	Press or slide	Stop playback/stop fast forward or rewind*	■ 4
Stop recording	■ 4	Pause playback	Slide Ⅱ一時停止 (pause) in the direction of the arrow. The battery indicators go off. To release pause playback, slide Ⅱ一時停止 (pause) in the opposite direction.
Start recording during playback	 during playback (the unit becomes in the recording mode). The 録音 (recording) indicator lights. 		
Review the portion just recorded	Slide ▶▶/キュー (cue)・◀◀/レビュー (review) toward ◀◀/レビュー(review) during the recording.	Fast forward	Slide ▶▶/キュー (cue)・◀◀/レビュー (review) toward ▶▶/キュー (cue) during stop.**
Pause recording	Release it at the point to start playback. Slide II—時停止 (pause) in the direction of the arrow. The 録音 (recording) and 電池(battery) indicators go off. To release pause recording, slide II—時停止 (pause) in the opposite direction.	Rewind	Slide ▶▶/キュー (cue)・◀◀/レビュー (review) toward ◀◀/レビュー (review) during stop.**
		Search forward during playback (cue)	Keep ▶▶/キュー (cue)・◀◀/レピュー (review) sliding toward ▶▶/キュー (cue) during playback and release it at the point you want.**
Take out a cassette		Search backward during playback (review)	Keep ▶▶/キュー (cue)・◀◀/レビュー (review) sliding toward ◀◀/レビュー (review) during playback and release it at the point you want.**

Select the 2.4 cm tape speed for recording, if you play back the recorded tape with another unit. Otherwise, the sound quality may be changed.

Tape counter F

Before recording, press the reset button of the テープカウンター (tape counter). It is useful for finding the beginning of the recording

Notes on VOR (Voice Operated Recording)

- The VOR system depends on the environmental conditions. If you cannot get the desired results, set VOR to \$11 (off).
- When you use VOR in a noisy place, the unit will stay in the recording mode. If the sound is too soft, on the contrary, the unit will not start recording.

Using the recording mode selector G

Set 録音モード (recording mode) to the desired position depending on the recording situation. 講義 (lecture): to record the sounds from where the unit is aiming (uni-

directional). It is useful to record during a lecture. The sensitivity is high. 会議 (meeting): to record at meetings or in a quiet or spacious place (omnidirectional). The sensitivity is high

口述 (dictation): to record for dictation or in a noisy place (omnidirectional). The sensitivity is low

To monitor the sound F

Connect the earphone to イヤホン (earphone) jack. The monitor volume cannot be adjusted by the 音量 (volume) control.

Recording cue marks F

While recording, you can record a special signal on the tape to mark a At the desired position, push $\pm \neg \neg \neg \neg \neg \neg$ (cue marker) to record a signal. The 録音 (recording) indicator goes off for a while and a signal will

be recorded on the tape. If you want to record a signal longer than that,

because the winding speed varies from the beginning to the end of the tape.

push キューマーカー (cue marker) as long as you want. During cue and review, you will hear the beep sound at the signal position. During playback, you will hear the signal with low frequency.

- •We recommend recording cue marks when there is a break in the sound.
- The beep sounds during cue differs from that during review. • The beep may sound differently depending on the marked position on the tape

At the end of the tape

cover the tab hole with adhesive tape.

Playing a Tape

recording. E-b

3 Press ►. E-©

Precautions the locked buttons will be released automatically (Automatic shut-off On power After fast forward or rewind, be sure to set $\blacktriangleright \blacktriangleright / \ddagger \lnot - \text{(cue)} \cdot \blacktriangleleft \blacktriangleleft / \nu$ Operate the unit only on 3 V DC

To prevent a cassette from being accidentally recorded over H

Break out and remove the cassette tabs. To reuse the cassette for recording.

1 Insert a cassette with the side to start playing facing the lid.

4 Adjust the volume by the 音量 (volume) control. E-ⓒ

Press or slide

2 Set テープスピード(tape speed) to the same speed as that used for

* If you leave the unit after the tape has been wound or rewound, the batteries will be

** The tape moves faster in the rewind/review mode than in the fast forward/cue

(review), the $\blacktriangleright \blacktriangleright / \neq \neg -$ (cue) $\cdot \blacktriangleleft \blacktriangleleft / \blacktriangleright \not \sqsubseteq \neg -$ (review) switch may not return to the

center position when you release it. In this case, push it back to the center position to

Slide the ファーストプレイバック (fast playback) switch in the direction of

To return to the original speed, slide the switch to the original position.

Dubbing onto another tape recorder | |

You can position the unit to record the sound more clearly using the stands.

You can choose from the two types of stands depending on the recording

To attach the stand if it is accidentally detached J-b

Connect another tape recorder using the RK-G64 connecting cord (not

Set this unit to the playback mode and another tape recorder to the

If the tape is completely rewound while searching backward during playback

consumed rapidly. Be sure to depress ■ 41.

To increase the playback speed

the arrow. The playback speed will be increased.

How to Use the Stands

start playback

recording mode

situation. **J**-@

Attach it as illustrated.

In the recording or playback mode, the tape stops at the end of the tape and

On the unit

• Use only the (MICROCASSETTE)[™] (standard microcassettes) with this unit. Non-standard cassettes cannot be used because their "L" dimension (A) is different

For AC operation, use the AC adaptor recommended for the unit. Do not use any

other type. For battery operation, use two R6 (size AA) batteries.

- Do not leave the unit in a location near heat sources, or in a place subject to direct sunlight, excessive dust or mechanical shock.
- Should any solid object or liquid fall into the unit, remove the batteries or disconnect
- the AC power adaptor, and have the unit checked by qualified personnel before operating it any further.
- Keep personal credit cards using magnetic coding or spring-wound watches etc. away from the unit to prevent possible damage from the magnet used for the
- When you do not use the unit for long, remove the batteries to avoid damage caused by battery leakage and subsequent corrosic
- If the unit has not been used for long, set it in the playback mode and warm it up for a few minutes before inserting a cassett

Troubleshooting

A cassette cannot be inserted.

→ has been already pressed

Should any problem persist after you have made these checks, consult your

- → The cassette is being inserted in the wrong way. (The cassette should be inserted in the lid with the tape side facing upward.)
- cannot be pressed.
- → There is no cassette in the cassette compartment. The cassette tab has been removed.
- or ➤ cannot be pressed.
- → The tape has reached the end → After the automatic shut-off, **11**一時停止 (pause) is slid in the direction of the
- The unit does not operate.
- → The batteries have been inserted with incorrect polarity. → The batteries are weak. Replace both batteries with new ones.
- → **II**一時停止 (pause) is slid in the direction of the arrow.
- → The AC power adaptor or car battery cord is connected to the unit only and you are going to use the unit on batteries.
- No sound comes from the speaker
- → The earphone is plugged in. → The volume is turned down completely
- The sound drops out or comes with excessive noise.
- → The volume is turned down completely

→ The batteries are weak. Replace both batteries with new ones. → The head is contaminated. See "Maintenane

During cue/review, the tape stops or does not run. Or you

cannot fast-forward or rewind → The batteries are weak. Replace both batteries with new ones.

Tape speed is too fast or too slow in the playback mode. speed as that used for recording.

Tape speed is faster than the normal playback speed. → The ファーストプレイバック (fast playback) switch is slid in the direction of

Recording cannot be made. → The batteries are weak. Replace both batteries with new ones. → The head is contaminated

→ The VOR switch is set to λ (on). When you do not use VOR, set it to $\frac{1}{2}$ (off). → Set the 録音モード (recording mode) selector firmly at the correct position. Recording is interrupted

Recording cannot be erased completely.

→ The head is contaminated.

Maintenance |L|

To clean the tape head and path

Press ► and wipe the head ①, capstan ② and the pinch roller ③ with a cotton swab, moistened with alcohol every 10 hours of use.

To clean the exterior

Use a soft cloth slightly moistened in water. Do not use alcohol, benzine or